



**SEASONAL
LIVING®**

Provenance Signature Collection by Laura Muller

Meditation Bench Assembly Instructions

S1568100215 Rectangle Meditation Bench Top

S1568100225299 Meditation Bench Bases

SeasonalLiving.com

Tel 512-554-5738

Fax 512-681-9188

sales@SeasonalLiving.com

Seasonal Living

Park Tower, Suite 350

4009 Banister Lane

Austin, Texas 78704

United States of America

ASSEMBLY INSTRUCTIONS SUMMARY

READ ALL INSTRUCTIONS PRIOR TO ASSEMBLY AND CHECK THAT YOU HAVE ALL PARTS AND TOOLS PRESENT. DO NOT ASSEMBLE THE DINING TABLE IF YOU ARE MISSING ANY PARTS.

Do NOT use power tools to assemble and tighten bolts. Hand-tighten all bolts ONLY using the provided Allen Key.

Step 1: Locate the Assembly Parts in the Bench Top carton box.

Step 2: Unpack the Bench pedestal bases and move them to desired location.

Step 3: Adjust the Bench pedestal glides on each base.

Step 4: Install the Bench Top on top of the pedestal bases.

Step 5: Make final adjustments.

IMPORTANT ASSEMBLY INFORMATION

1. Follow all packaging handling instructions (if any).
2. Check that you have all parts prior to assembly. Do not assemble this Bench without all parts being available
3. ALL assembly parts can be located on the underside of the Bench Top.
4. Read the Product Care Instructions prior to assembling the Bench.

Continued on next page



SEASONAL LIVING®

Revised 04.05.2023

1

Provenance Signature Collection by Laura Muller Assembly Instructions

5. Do not attempt to assemble this Bench without the assistance of 2 physically capable adults. This product is heavy, lack of physical assistance may result in product damage or physical injury to you or others.
 6. Identify desired location of the Bench and check that the ground surface is solid, flat and level.
 7. We recommend that you use 1 or 2 soft, clean moving blankets to help you protect the product post un-packing and prior to assembly.
 8. DO NOT drill or use any other power tools to assemble or tighten the bolts on any part of this dining table. Only use the Allen Key to tighten all bolts.
 9. Seek out and check that you have all the adjustable glides (on the dining table base) and that they screw and unscrew easily.
 10. Contact Seasonal Living should you require assembly assistance:
Email: Service@SeasonalLiving.com **Tel:** +1-512-554-5738 Mon-Fri 9am to 4pm US Central time.
-

PARTS LIST

A

Bolt M8 x 25 mm
16 PCS




B

FlatWasher .31" x .75"
16 PCS




C

Allen Key .20"
1 PC




Continued on next page

Provenance Signature Collection by Laura Muller Assembly Instructions



STEP 1: LOCATE THE ASSEMBLY PARTS IN THE BENCH TOP CARTON BOX

- Open the carton box containing the Bench Top.
- Remove all parts: 2 metal assembly bracket and 1 red plastic bag containing the assembly parts.
- Check against these instructions that you have all the correct counts of assembly parts.



STEP 2: UNPACK THE BENCH BASES & MOVE THEM TO THE DESIRED LOCATION OF ASSEMBLY AND USE

- Position the assembly brackets on top of the dining table pedestal bases, lining up the holes of the assembly brackets with the holes in the pedestal bases.


Continued on next page

Provenance Signature Collection by Laura Muller Assembly Instructions

- b) Place a washer over each of the 4 centrally located holes on top of the assembly bracket on each pedestal base.
- c) Thread a bolt through the washer and through the assembly bracket and hand tighten using the Allen Key. Repeat with all remaining washers and bolts (total 4 washers and 4 bolts) for each table base.
- d) Make sure the assembly brackets are well secured to the Bench pedestal bases.
- e) Recheck that the Bench pedestal bases are positioned in the final desired location.

STEP 3: ADJUST BENCH PEDESTAL BASE GLIDES (located on the base of each base)

- a) Adjust the leveler glides to desired height on each pedestal base.




STEP 4: MOVE THE BENCH TOP ON TOP OF THE BENCH PEDESTAL BASES AND ATTACH

- a) Lift all sides of the Bench Top at the same time.
- b) Position the Bench Top centrally over the pedestal bases using the holes in the Bench as a guide to line up with the holes in the assembly bracket.
- c) Using the remaining 4 bolts and 4 washers for each pedestal base, connect the tabletop to the assembly bracket.

Continued on next page

Provenance Signature Collection by Laura Muller Assembly Instructions



d) Hand tighten the bolts with the Allen Key and make sure the Bench Top is well secured to each assembly bracket and each Bench Pedestal base.

STEP 5: MAKE FINAL ADJUSTMENT TO BOTH PEDESTAL BASE GLIDES FOR IDEAL BENCH HEIGHT

- a) Check that the assembled Bench is the correct height for your needs.
- b) Adjust glides if necessary.
- d) Well done—you did it. Enjoy!

CLEANING & CARE

Treat all surfaces of the dining table with care. While the surface is scratch resistant, avoid items that can damage the surface material.

Clean all surfaces with a dry or damp, soft cloth on a regular basis.
DO NOT use any abrasive cleaners or liquids.

The assembly parts may loosen over time.
Periodically check that the top and base are well-secured.

For detailed product care instructions, read the instructions shipped with your dining table or visit SeasonalLiving.com and navigate to the product page for more information.